

MONTÁŽNÍ NÁVOD - BR06

1580, 1850, 1880, 1390, 1690

BR 06		1x		1		2x
		2		2x		4x
		3		1x		1x

